



The Dual Split-Second Sizer and The Duplicator 2 Accessory Instruction Sheet


60/40 Helium/Air Outlet



Hand-tight connect the 60/40 Helium/Air Outlet to the inflator.



Slide the neck of the balloon down to the large tapered sealing area of the outlet and pinch between thumb and forefinger.



When the automatic inflator shuts off, quickly remove the balloon from the filling outlet. If the balloon is not removed quickly the gas will escape out of the air intakes of the outlet.

Conwin #53413

HI-FLOAT® Outlet



Hand-tight connect the HI-FLOAT® Outlet to the inflator. Slide the balloon over the filling outlet and pinch between thumb and forefinger.



After the automatic inflator shuts-off remove the balloon from the filling outlet. Make sure to pump the HI-FLOAT® into the center of the balloon without getting any on the neck of the balloon. This will prevent the filling outlet from clogging.

Conwin #53411

Air Compressor Hook-Up



The Air Compressor Hook-Up, with quick-disconnect fittings, allows user to operate Dual Split-Second Sizer up to 12-ft. away from the compressor. Hook-Up air line also includes a filter that prevents dirt and moisture from entering the inflator.

Conwin #53415

ConwinOnline.com

Our site features Conwin's complete line, balloon galleries, inspirational ideas, seasonal designs, step-by-step projects, and so much more.

Visit www.ConwinOnline.com today!



Online
Projects
Designs
Galleries
...and more!

ConwinOnline.com

Conwin's Tools of the Trade Video

Learn more about the entire line of Conwin products from the popular Precision Air Inflator to the spectacular Confetti Cannon! You'll also see many award-winning productions by leading balloon artists! Visit ConwinOnline.com's Education Center to see our complete line of videos.



CONWIN INC.
4510 Sperry Street • Los Angeles, CA 90039
Phone (323) 245-2842 FAX (818) 246-6862

10052001

Visit www.ConwinOnline.com today!