

Cylinder Safety Wall Bracket Instructions

How to Mount your Wall Bracket



Hold Cylinder Safety Wall Bracket against the wall in the desired location, and outline mounting holes with a pencil. The bracket should be mounted so that the Velcro® strap is just below the crown of the cylinder.

Mounting on a Wood Surface

- Drill a 1/8" pilot hole.
- Mount with screw provided.

Mounting on a Drywall Surface

- Drill a 1/4" pilot hole.
- Insert the anchor into the pilot hole.



Mounting Multiple Brackets

When mounting multiple brackets in one workstation, bolt a 2" x 4" board to the wall, and then use the wood screws to mount the brackets in a row. Bracket also works well when mounted on the floor of a van to secure cylinder during transportation.