

Archline Dispenser Pack Instructions

How to Load the Archline



1. Place the archline in the dispenser pack with the line feeding from the base of the spool(s).

2. Attach the Line Tensioner approximately 6 inches from the end of the line. Push the red button on the Line Tensioner to expose the metal hook on the top of the ball. Thread the archline under the hook and release the button to capture the line. The Line Tensioner will prevent the archline from free spinning inside the pack when balloons are attached to the line.

3. Feed the archline through the grommets in the lid and close the Velcro® flap. Pull the archline to remove any slack inside the pack.